







LX0896 MINI PROTOS - Ultra Tail Rotor Hub - Thrusted - Silver
LX0897 MINI PROTOS - Ultra Tail Rotor Hub - Thrusted - Red
LX0898 MINI PROTOS - Ultra Tail Rotor Hub - Thrusted - Black


**STEP 1****STEP 2****STEP 3****STEP 4**

Assembly Finish



Assembly Note

-Picture bottom show Lynx MP tail rotor hub assembled with Lynx tail pitch slider.
 -Add Loctite 242 (medium) on screws M2 x 8
 -In case you will use STD MP tail pitch slider refer to MP user manual



LYNX
HELI INNOVATIONS