


LX1097 MICRO SERVO SAVER ARM - SET 3 PC


STEP 1




STEP 2



Assembly finish



Note: T-Rex 150 Linkage ball and servo arm set-up
Use this hole when used in T-Rex 150



NOTE: During assembly this screw must lock loose, otherwise the servo arm cannot rotate in case of crash. We suggest locking the screw completely, and then open half of turn. This operation is mandatory for the perfect function of the system.